


Input parameters  
(types: double, int, string)

Mem-structures initialised  
on "host", optionally send  
sub-problem to K mpi "hosts"

Transfer data to GPU:



Save output to disk

## McStas simulation flow on CPU vs GPU

- Optionally split by K mpi

### A. CPU code execution

```
for (int i=0; i<ncount; i++) {  
  // Single-threaded execution  
  Source_trace()  
  // logic + coord transform  
  Monitor_1_trace()  
  // logic + coord transform  
  Optic_1_trace()  
  // logic + coord transform, e.g.  
  // next particle if ABSORBed  
  Monitor_2_trace()  
  // logic + coord transform  
  Sample_trace()  
  // logic + coord transform  
  Detector_trace()  
}
```

- Optionally split by K mpi
- Optionally rep-loop if ncount > 2e9)

### B. GPU code execution

```
for (int i=0; i<ncount; i++) {  
  // generate and calc. i'th particle in sep. thread  
  Global GPU-mem  
  Source_trace()  
  // logic + coord transform  
  Atomic, "thread-locked" array-access  
  Monitor_1_trace()  
  // logic + coord transform  
  Optic_1_trace()  
  // logic + coord transform, e.g.  
  // next particle if ABSORBed  
  Atomic, "thread-locked" array-access  
  Monitor_2_trace()  
  // logic + coord transform  
  Sample_trace()  
  // logic + coord transform  
  Atomic, "thread-locked" array-access  
  Detector_trace()  
}
```

## 'Standard layout' - 1

- 1 big parallel loop

```
#pragma acc parallel loop num_
for (unsigned long pid=0 ; pid
...
raytrace(_particle);
}
```

```
With
int raytrace(_class_particle* _particle) { /* single event propagation, called by
mccode_main for mini:TRACE */
...
_class_particle _particle_save=_particle;
/* the main iteration loop for one incoming event */
while (!ABSORBED) { /* iterate event until absorbed */
/* send particle event to component instance, one after the other */
/* begin component arm=Arm() [1] */

/* coordinate change pr. comp, trace fct. pr. comp until the end of comp list / ABS*/
...
/* begin component source=Source_simple() [2] */
mcccoordschange(_source_var._position_relative, _source_var._rotation_relative,
_particle);
if (!ABSORBED && _particle->_index == 2) {
...
class_Source_simple_trace(&_source_var, _particle);
/* restore-logic etc, then next comp */
....
} /* while !ABSORBED */

DEBUG_LEAVE()
particle_restore(_particle, &_particle_save);
DEBUG_STATE()

return(_particle->_index);
} /* raytrace */
```

## 'FUNNEL layout'

- potentially multiple kernels

- Particles traced in bunches of size 'livebatchsize':

With a split, minimum:

1. Initial kernel
2. Sorting kernel
3. Second kernel

Followed by 'grouped' components, e.g. between SPLIT's

```
#pragma acc parallel loop present(particles[0:livebatchsize])
for (unsigned long pid=0 ; pid < livebatchsize ; pid++) {
    _class_particle* _particle = &particles[pid];
    _class_particle _particle_save;

    // arm
    if (!ABSORBED && _particle->_index == 1) {
        _particle->_index++;
    }
    // Comps up to monochromator in e.g. PSI_DMC
    ...
}

// SPLIT with available livebatchsize
long mult_foc_mono;
livebatchsize = sort_absorb_last(particles, pBuffer, livebatchsize, gpu_innerloop, 1, &mult_foc_mono);
//printf("livebatchsize: %ld, split: %ld\n", livebatchsize, mult);

#pragma acc parallel loop present(particles[0:livebatchsize])
for (unsigned long pid=0 ; pid < livebatchsize ; pid++) {
    _class_particle* _particle = &particles[pid];
    _class_particle _particle_save;

    // foc_mono
    if (!ABSORBED && _particle->_index == 21) {
        ...
        mccoordschange(_foc_mono_var._position_relative, _foc_mono_var._rotation_relative, _particle);
        _particle_save = *_particle;
        class_Monochromator_2foc_trace(&_foc_mono_var, _particle);
        if (_particle->_restore)
            particle_restore(_particle, &_particle_save);
        _particle->_index++;
    }
    ...
}
```

## ‘MULTIKERNEL layout’

- potentially multiple kernels

- Like FUNNEL but there will always be a kernel pr. comp
- Define to globally use / not use ‘absorption sort’ kernels in between comp kernels
- Rationale:
  - Allow more fine-grained profiling?
  - Alternative: Can we add pragmas for profiling / adding nvtx like points in acc regions?